

1535 Owens Road, Jacksonville, FL 32218 - (904)741-4850 - FAX (904)741-4853

www.turboaction.com

CHEETAH SCS Shifter Cable Replacement Installation Instructions

FIRST, READ INSTRUCTIONS CAREFULLY, THEN PROCEED TO INSTALL CABLE PER THESE INSTRUCTIONS.

Kit Includes: 1 - Cable

1 - Set of instructions

<u>STEP #1</u>: Preferably, remove the shifter from vehicle.

STEP #2: Remove cable clamp screw on one side and loosen the other screw far enough to

remove cable from under the clamp, Fig. #1. Note: The shifter mounting bracket and clamp must be placed back into the same set of holes in the shifter rail.

STEP #3: Holding the Terminal Block, break the jam nut loose on the cable, Fig. #1&2. Turn

the cable counterclockwise and remove from the Terminal Block.

STEP #4: Reinstall cable per Fig. #1&2, and be sure clamp goes into the groove in the

cable. **DO NOT OVER TIGHTEN** screws. If cable is stretched out straight and a second person turns the the cable clockwise while you guide into Terminal Block,

things will go easier. Now adjust as shown.



