

CHEETAH SCS LH&RH Torsion Spring Replacement

www.turboaction.com

Installation Instructions

FIRST, READ INSTRUCTIONS CAREFULLY, THEN PROCEED TO INSTALL PIN AND SPRINGS AS NEEDED.

Kit Includes: 1 - U70191 Torsion Spring RH

1 - U70192 Torsion Spring LH

1 - U70193 Pin Retains Torsion Springs

1 - ---- Set of instructions

STEP #1: Preferably, remove the shifter from vehicle.

STEP #2: Note position of each spring wire coming thru the housing, Fig.1.

STEP #3: Note drivers side how the two springs must be installed as shown, Fig. 2&3.





